

MODEL: 50010BRZ

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

READ INSTRUCTIONS ALL THE WAY THROUGH PRIOR TO ASSEMBLY.

THIS FOUNTAIN SHOULD TAKE APPROXIMATELY 15 MINUTES TO ASSEMBLE.


MAKE SURE ALL PARTS ARE FIRMLY TIGHTENED.

UNPACK THE FOUNTAIN


YOU SHOULD HAVE RECEIVED THE FOLLOWING PARTS: SPRAYER, LID, PLASTIC TUBE, UPPER RESERVOIR, SLATE PANEL, PUMP, LOWER RESERVOIR AND BASE.

FOUNTAIN ASSEMBLY


1. FEED POWER CORD TOWARDS BOTTOM OF BASE, MAKE SURE POWER CORD COMES OUT FROM CHANNEL ON BOTTOM OF THE BASE, THEN PLACE LOWER RESERVOIR ONTO TOP OF BASE.



2. PLACE SLATE PANEL ONTO TOP OF THE LOWER RESERVOIR.




3. ATTACH PUMP TO RUBBER HOSE, THEN PLACE UPPER RESERVOIR ONTO TOP OF THE SLATE PANEL.



* IF THE LID AND SPRAYER ARE NOT DESIRED, SKIP TO STEP #7.

** IF THE LID AND SPRAYER ARE DESIRED, FOLLOW THE INSTRUCTIONS AS BELOW.


4. ATTACH PLASTIC TUBE TO ROD IN THE UPPER RESERVOIR.



MODEL: 50010BRZ
ASSEMBLY INSTRUCTIONS
READ AND SAVE THESE INSTRUCTIONS


FOUNTAIN ASSEMBLY

5. PLACE LID INTO UPPER RESERVOIR, MAKE SURE THE PLASTIC TUBE INSERTED INTO HOLE IN LID.




6. ATTACH SPRAYER TO PLASTIC TUBE IN LID.

NOTE: YOU CAN ADJUST THE WATER FLOW CONTROL VALVE TO CONTROL THE SPEED OF THE WATER FLOW.



7. FILL UPPER RESERVOIR WITH 0.6 GALLONS OF WATER TO COMPLETELY SUBMERSE THE PUMP.

NOTE: DISTILLED WATER IS RECOMMENDED TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD-UP.



8. PLUG POWER CORD INTO AN OUTLET, YOUR NEW FOUNTAIN IS READY FOR USE.

AVAILABLE PARTS ARE:
PUMP1008 (PUMP)
SPRAYER-MUSHRM (SPREYER)

MODEL: 50010BRZ

ASSEMBLY INSTRUCTIONS

READ AND SAVE THESE INSTRUCTIONS

TROUBLE SHOOTING:

1. IF YOUR FOUNTAIN DOES NOT WORK, CHECK PLUG AT THE SOCKET. MAKE SURE THE PLUG IS FULLY AND PROPERLY INSERTED INTO THE WALL OUTLET.
2. NEXT CHECK TO MAKE SURE THE OUTLET IS POWERED.
3. IF THE FOUNTAIN STILL DOES NOT WORK, PLEASE CONTACT YOUR DISTRIBUTOR OR PLACE OF PURCHASE.

SPLASHING DISCLAIMER:

SPLASHING MAY OCCUR WHEN FOUNTAIN IS INITIALLY TURNED ON. PROTECT SURROUNDING SURFACES AS NEEDED.

IMPORTANT PUMP INFORMATION:

PUMP MUST BE FULLY SUBMERSED IN WATER WHILE OPERATING.

WATER:

TO REDUCE MINERAL DEPOSITS AND BACTERIA BUILD UP THE USE OF DISTILLED WATER IS RECOMMENDED.

IMPORTANT SAFETY INSTRUCTIONS:

THIS FOUNTAIN IS RATED FOR INDOOR OR OUTDOOR USE.

WARNING:

* ONCE A WEEK INSPECT FOUNTAIN, FLOOR AND ADJACENT WALL FOR MOISTURE BUILD-UP AND CLEAN AS NECESSARY. THIS IS ESPECIALLY IMPORTANT FOR HUMID ENVIRONMENTS.

** THIS UNIT MUST BE CONNECTED TO A SUPPLY CIRCUIT THAT IS PROTECTED BY A GROUND FAULT CIRCUIT INTERRUPTER (GFCI). THE GFCI SHOULD BE TESTED ON A ROUTINE BASIS. TO TEST THE GFCI, PUSH THE TEST BUTTON. THE GFCI SHOULD INTERRUPT POWER. PUSH THE RESET BUTTON. POWER SHOULD BE RESTORED. IF THE GFCI FAILS TO OPERATE IN THIS MANNER, THE GFCI IS DEFECTIVE.